Setting the Zero

Does the Pendulum Arm clear the surface when Released

Yes

Lock Pendulum Arm into release mechanism

Rotate pointer anti-clockwise so pointer counterweight touches nylon stop

Release the Pendulum Arm. Catch on return swing and secure in release mechanism.

Does Pointer read zero?

Yes

Repeat 3 times

Setting zero completed!

No

Adjust friction rings. Rotate friction rings slightly clockwise if reading is <0 and anti-clockwise if reading is >0

No

Raise the Pendulum arm by releasing reading clamp knob and rotating both adjustment knobs anti-clockwise

Munro Instruments, 44-45 Burnt Mill, Elizabeth Way, Harlow, Essex, CM20 2HU, UK
E info@munroinstruments.com / P +44 (0) 20 8551 7000 / www.munroinstruments.com
Company Registered Number: 06965050 VAT Number: GB 977 7939 30.